










THRU BEAM		THRU BEAM
BP Series For automatic- doors single/double beam		BP Series - For Automatic- Doors Single/Double Beam
P 40 Series For external panel mounting		12 V AC/DC RELAY OUTPUT
P 41 Series For external wall mounting		24 V AC/DC RELAY OUTPUT
P 44 Series Battery supply for external wall mounting		12-24 V AC/DC RELAY OUTPUT
P 45 Series		230 V AC RELAY OUTPUT
Accessories		
Solar Cell SCP44		

© 2007 Advfit Automation Sdn Bhd. All Right Reserved.



AdvFit Automation Sdn Bhd (Co. No. 587996-T)

Penang Office: No. 43, Persiaran Mahsuri 1/1, Sunway Tunas, 11900 Bayan Lepas, Penang , Malaysia.
 Tel: +604-644 6113 Fax: +604-643 0113
 E-mail: Sales@advfit.com

Selangor Office: No. 40A , Jalan Anggerik Vanilla AD31/AD, Seksyen 31 , Kota Kemuning ,
 40460 Shah Alam , Selangor , Malaysia .
 Tel: +603-5121 9727 Fax: +603-5122 9727
 E-mail: Sales@advfit.com

WEBPAGE: <http://www.advfit.com>
 : <http://www.advfitonline.com>